Deep Fryer

Model CE1950DF

INSTRUCTION MANUAL

PLEASE SAVE THESE INSTRUCTIONS

Dear Valued Customer

Thank you for purchasing a *CASCADE* appliance.

We understand the importance of your purchasing decision, and appreciate your final choice to introduce this *CASCADE* product into your home.

Your *CASCADE* appliance is recognized as a quality product at an affordable price, and is proudly supported by our after sales service team. We encourage you and your friends to choose from the range of *CASCADE* appliances available exclusively to The Warehouse.

TECHNICAL INFORMATION

Please make sure that your house installation voltage corresponds to the voltage marked on the unit.

Mains supply:	230V~ 50 Hz – AC only
Rated Power:	1300 watts

SERVICE

In the unlikely event of failure or for product information please contact the below help lines.

New Zealand call 0800 89 85 80
Email: service@opnz.com
Australia call Toll Free 1 800 858 011

BEFORE FIRST USE

1. Your *CASCADE* Deep Fryer has been packaged carefully to ensure the product reaches you in good condition. If the product has been damaged, dropped, has a malfunction in any way, or if the flexible cord is damaged, immediately contact your retailer for replacement or repair.
2. Carefully unpack your *CASCADE* Deep Fryer. Make sure you do not discard any packaging material until all parts of the appliance have been found.
3. Carefully wipe the exterior and interior bowl of the appliance with a damp cloth to remove any dust that may have accumulated. Dry with a dry towel. Do not use abrasive cleaners.
   WARNING! Do not immerse in water or any other liquids.
4. Wash the accessories in warm soapy water. Dry with a dry towel.
5. The appliance is now ready for operation.

OPERATION

- Always place the appliance on a clean, flat and non-slippery surface before operating.
- Always place the appliance on a heat resistant surface, as the appliance will reach high temperatures.
- WARNING! Always leave a gap of approximately 20 cm around the exterior of appliance. Never use near curtains, walls, under cupboards or other flammable materials.
- **WARNING! DO NOT LET SUPPLY CORD HANG OVER THE EDGE OF ANY BENCH OR TABLETOP. AS THERE MAY BE A RISK OF SCALDING SHOULD YOUNG CHILDREN PULL THE APPLIANCE FROM THE BENCH OR TABLETOP.**

- Plug the power cord into a suitable mains outlet corresponding to the supply requirements of your appliance, 220-240V ~50Hz – AC only.
- Always add the required oil level before switching on the appliance. Pour required oil, up to 1.6 litres, into the bowl until desired level within the MIN – MAX level is reached.
- WARNING! Do not fill below minimum or exceed maximum level.
- Remove cooking basket before heating.
- Close lid securely until it locks.
- Preheat oil by selecting 190°C setting on thermostat. Indicator light will glow indicating the heating cycle is on.
- When pre-heating is completed, open the lid by pressing the 'release / open' button. Place food into the cooking basket. Lower the basket into the cooking bowl by pressing 'release' button on the handle and lowering downwards completely. NOTE: the basket may be raised or lowered with the lid open or closed.
- Select desired cooking temperature by altering the temperature controller to the desired temperature.
- Indicator light will glow indicating heating cycle is on.
- Do not place food directly into cooking bowl of appliance.
- Close the lid until it locks.
- Once the desired cooking has lapsed, raise the basket by pulling the handle upwards until it locks into the raised position.
- Turn the temperature control to the 'OFF' position
- Open the lid by pressing lid 'release' button.
- Allow cooking oil to drain from the food basket while in a raised position. When completely drained, remove the basket from the appliance and place on a heat resistant surface.

- WARNING! Do not use solid products such as animal fats, butter or margarine. Use only liquid oils. Do not put water or other liquids into hot oil, which may cause splattering and increase the risk of burns. Oil retains its heat for long periods. Extreme care must be taken when moving this appliance if it contains hot oil, liquids or food of any type.
- WARNING! Hot steam and heat may be expelled when opening the lid. Use caution in order to avoid personal injury. Do not block the vents of this appliance.
- WARNING! Do not touch hot surfaces.

NOTE: The first time you use your appliance; there may be a small amount of smoke and odor. This is normal**.** It is due to the heating of a protective coating, placed on the heating elements, to protect the heating elements during shipping.

Cooking Guide

Food	Temperature	Approx. cooking time
Chips	190°C	4-7 minutes
Potato Wedges	170°C	7-10 minutes
Fish Fillets (battered)	150°C	7-10 minutes
Chicken Pieces	170°C	12-18 minutes

CLEANING AND CARING

- Always disconnect your *CASCADE* Deep Fryer from the mains supply before cleaning.
- Always allow your appliance to cool completely before cleaning. WARNING! Oil retains its heat for long periods. Extreme care must be taken when moving this appliance if it contains hot oil, liquids or food of any type.

CASCADE

- Never immerse your appliance in water or other liquids.
- Remove the detachable lid completely from the appliance. Remove the filters from the lid before cleaning. Wipe with a warm damp cloth and mild dishwashing liquid. Dry with a dry towel. Do not immerse the lid completely in water.
- Drain oil or other liquid completely from bowl.
- After removing contents completely from bowl, wipe interior of bowl with an absorbent paper towel, then wipe with a warm soft cloth with a small amount of mild dishwashing liquid. Dry with a dry towel.
- Wipe the exterior of the appliance with a warm soft damp cloth. Dry with a dry towel.
- Do not use harsh abrasives as they may damage the non-stick cooking surface or the exterior finish.
- Wash the accessories in warm soapy water. Dry with a dry towel. Do not wash the basket in a dishwasher.
- Replace the charcoal filter after every 15 uses or as required to maintain proper operation of the fryer.
- Store your appliance in its original box or in a dry cupboard.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Carefully read these instructions before using your appliance.
2. VERY IMPORTANT: Do not immerse in water or other liquids or use near washbasins or sinks. Ensure that the appliance does not get wet (water splashes etc.) and do not use it with wet hands.

3. Safely dispose of plastic bags and other components of the packaging. They may be potentially dangerous to children.
4. Unplug from mains outlet when appliance is not in use, before attaching or removing accessories, and before cleaning.
5. An appliance dropped or damaged should not be used until examined by a service engineer.
6. Do not permit the mains lead to come in contact with hot objects.
7. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
8. CAUTION: Keep out of reach of children. This appliance is not intended for use by young children or infirm persons. Young children must be supervised to ensure that they do not play with the appliance
9. Use this appliance only for its intended use. Use only genuine attachments supplied by an authorised Service Dealer.
10. This appliance is intended for household use only and not for commercial or industrial use.
11. The appliance should not be used outdoors, placed near a hot gas or electrical burner or placed in a heated oven.
12. WARNING! Do not let the cord hang over edge of table or counter. Risk of scalding.
13. WARNING! An appliance should never be left unattended when plugged in.
14. WARNING! Hot steam may be ejected when opening or removing the lid.
15. WARNING! Always place the appliance on a heat resistant surface, as the body will reach high temperatures.

CASCADE

16. WARNING! Ensure adequate ventilation; keep an open space of approximately 20 cm all around the appliance.
17. WARNING! Do not use the appliance near flammable materials such as curtains, walls or under cupboards.
18. If appliance is to be used by a third party, please supply the instruction manual with it.
19. No liability can be accepted for any damage caused by non-compliance with these instructions or any other improper use or mishandling.

CAUTION

Do not attempt to service this appliance yourself. Refer servicing to qualified service personnel.

ORIENTAL PACIFIC INTERNATIONAL LIMITED

Guarantee Card

This product is guaranteed against faulty materials and workmanship for a period of two years from the date of purchase. The obligation to the purchaser under this warranty is limited to servicing the unit and replacing defective parts when the product is returned freight prepaid to the retailer. This warranty becomes void if the product has been tampered with, damaged by accident, damaged in any other way by improper use or has been purchased second hand. All production orders have quality inspections. In the unlikely event of a deficiency, please contact the retailer from whom this product was purchased.

WARRANTY FOR APPLIANCES USED COMMERCIALLY LIMITED TO 90 DAYS

Type of Appliance: .....
Model Number: .....
Purchase Date: .....
Store Purchased: .....
Name: .....
Address: .....
.....
Phone Number: .....
.....

IMPORTANT!

Please retain this warranty card along with your purchase receipt. Please do not post to the Retailer or Importer. If service is required, both of these documents are to be returned with the appliance to your retailer, otherwise a fee may be charged.

Oriental Pacific International Limited
P O Box 302-158
North Harbour
Auckland 1130
New Zealand

New Zealand call 0800 89 85 80
Email; service@orientalpacific.com
Australia call Toll Free 1 800 858 011